

HOW TO INSTALL THE ERGON BICYCLE CHILD'S SEAT

Congratulations on having chosen an OKBABY child's bicycle seat. You have purchased a comfortable, top quality product designed to satisfy your child's needs. Before assembling and installing the seat on your bicycle, read the following instructions and advice carefully. This will enable you to install the bike seat properly and keep it working at its best. Keep these instructions to hand for future reference. They will come in useful if you need to remount the seat on another bike.

1. TECHNICAL FEATURES

- The Ergon bike seat has been officially approved for carrying babies from approximately 9 months to 6 years of age, with a maximum weight of 22 kg. The seat must be installed behind the rider as indicated in the instructions.
- The seat is suitable for bikes equipped with 26"/28" wheels and round section frames from 28 mm to 40 mm in diameter.
- It cannot be secured on oval or square section frames.
- It cannot be installed if the carrier on the bicycle is wider than 15 centimetres. In this case, dismount and replace the carrier with a narrower model
- Ask your dealer if you are not sure whether the seat is suitable for your bicycle.

2. FASTENING MATERIAL

- 1 hexagonal head screw 60 mm in length
- 1 metal fixing plate
- 1 star-shaped handwheel
- 1 self-blocking screw nut
- 4 round head screws 50 mm in length (for
- fastening the support block)
- 4 hexagonal screw nuts (with toothed washer incorporated or separate for fastening the support block)
- 5 plastic adapters for different frame widths
- 1 allen wrench
- 1 instruction manual
- 1 metal plate for support block
- 1 plastic support block
- 1 metal tube

ASSEMBLING AND FASTENING THE SEAT

- g. A. Fit the support bar 1 into the holes 2.
- g. B. Position the metal fixing plate 3 as illustrated.
- C. Insert the screw 4 and tighten the handwheel 5 as shown, to fasten the plate.









